APPLICATION OF **PROFISIL®**

STEP BY STEP

KETTENBACH DENTAL
Simply intelligent

1	Carefully peel off the foil from the single-dose blister pack. Lift the foil near the brush and remove the brush.		**PROFISIL®**	No prophylaxis is required before application. If prophylaxis is performed, the varnish should be applied after scaling and polishing.
2	Peel off the remaining film to expose the varnish. Mix the contents briefly until they form a homogeneous mixture.			You do not need to dry your teeth before applying the varnish.
3	Apply a thin, even layer to all affected tooth surfaces.			**PROFISIL®** can be applied to all affected tooth surfaces.
4	Do not rinse or suction immediately after application. Recommend that the patient avoid brushing or flossing for at least four hours, or, if possible, postpone both until the next day.			**PROFISIL®** leaves your teeth feeling smooth and gives you a pleasantly refreshing sensation in your mouth!

1410984_4026